INSERT FOR COLT AUTOMATIC MACHINE RIFLE (R 75) HANDBOOK

4,50

Information Relating To

Colt Automatic Machine Rifle (R75A)

(with quickly demountable barrel)

COLT'S PATENT FIRE ARMS MFG. CO. Hartford, Connecticut, U. S. A.

(with quickly demountable barrel)

The information and data given in the following pages relating to Colt Automatic Machine Rifle (R 75 A), supplement the information and instructions given in the Colt Automatic Machine Rifle (R 75) Instruction Book.

The information given in the R 75 Handbook is generally correct for the Colt Automatic Machine Rifle (R 75 A). The barrel in the latter, however, is of the quickly demountable type and instructions for dismounting and mounting the barrel in the receiver are given in the following pages.

General Data

Weight	of	Rif	le	wit	h	Bir	bod	a	nd		
Maga	zine			*						21	lbs.
Weight	of Ba	arrel	wi	th (Cha	ngii	ng				
Hand	le .			۰.						$5\frac{1}{2}$	lbs.
Weight											
round	s) .									10	ozs.
Weight											
round	s) .								1 lb	. 10	ozs.
Weight	of Sli	ing S	Stra	аp						8	ozs.
Weight											
(inclu	ding	yok	e)						1 1	b. 3	ozs.

Length of Barrel	*					24	inches
Length of Rifle, ove	rall					431/2	inches
Sight graduated up	to 1	400	me	ters	5		
Gas Port from Muzz	zle					. 6	inches
Rate of Fire (nomin	al)		500	she	ots	per	minute
Aimed Shots per M matic							60
Rifle fires Caliber . tary Cartridge							

Regular Equipment with each rifle supplied on F. O. 9387 also F. O. 907 is as follows:— SPARE PARTS

2 Extractors

2 Extractor Springs

- 1 Ejector
- 1 Recoil Spring
- 2 Firing Pins
- 1 Sear Spring
- 1 Bolt Guide Spring
- 1 Connector

6 Extra Magazines

- 1 Magazine Catch
- 1 Magazine Catch Pin
- 2 Magazine Catch Springs
- 1 Gas Cylinder Tube Retaining Pin
- 1 Trigger Pin
- 1 Trigger Guard Retaining Pin
- 1 Recoil Spring Rod

ACCESSORIES

1 Leather Accessory Case

- 1 Magazine Filler
- 1 Combination Tool
- 1 Thong Cleaner with brush complete

- 1 Oil Can (filled)
- 1 Ruptured Cartridge Extractor
- 1 Gas Cylinder Cleaning Tool
- 1 Cleaning Brush for Chamber

$\begin{array}{c} \text{Colt Automatic Machine Rifle } (R_{75}A) \\ {}_{(\text{with quickly demountable barrel})}\end{array}$





Plate 2 View of rifle showing barrel dismounted

(with quickly demountable barrel)

To Dismount Barrel from Receiver, Proceed as Follows:

1. Pull back on operating handle until bolt is held in the fully drawn back position.

2. Pull bar A to the down position shown in illustration Plate 2, which will disconnect the gas cylinder tube (227B) from the gas cylinder tube bracket (56B) of the barrel.

3. With rifle inverted and using the combination tool or the point of a cartridge, pry barrel locking spring C (see Plate 3) out of engagement with notch in barrel, then push down on the barrel changing handle B making one-third of a turn, which will disengage barrel from segmental threads in receiver. Now pull the barrel straight out towards the front.

To Mount Barrel in Receiver, Proceed as Follows:

1. With the rifle held upright, enter the barrel into the hole in the receiver until barrel flange comes up against face of receiver (in doing this pry the barrel locking spring C outwards to allow flange of barrel to pass).

2. When barrel flange comes up against face of receiver, grasp the barrel changing handle B which is attached to the barrel and give one-third of a turn to the barrel in a clock-wise direction. This will allow the barrel locking spring C to snap into the notch in the barrel, thus preventing any circumferential movement of the barrel during firing.

3. Return bar A to position shown in Plate 1 making sure that gas cylinder tube (227B) and gas cylinder tube bracket (56B) engage, and rifle is ready for firing.

4 R 75 A 9-42



Plate 3

View showing barrel locking spring C held out with the point of a cartridge in order that the barrel may be turned in the receiver. Note rifle is inverted for convenience in handling, also that bolt is drawn back.

(with quickly demountable barrel)



Plate 4

Right-hand side view of rifle with magazine removed, showing barrel locking spring C which must be held out of engagement with notch in barrel before barrel can be turned in the receiver. Bolt must be in the fully drawn back position (with the sear of the trigger-guard engaging in notch in slide) and the bar A unlocked by pulling downwards as shown in illustration Plate 2, before attempting to turn the barrel. If any attempt is made to dismount the barrel without taking these precautions, breakage of parts can result.

4 6 J R 75 A 9-42



Plate 5

Component parts which are special for the Colt Automatic Rifle (R75A)

PART NO.	NAME OF PART	
56B	Gas Cylinder Tube Bracket, Front	
60K	Barrel	
104E	Rear Sight Leaf (meters)	
225D	Forearm Cover	
227B	Gas Cylinder Tube	
233	Barrel Locking Spring	
234	Barrel Adapter Locking Plunger	
235	Barrel Adapter Locking Plunger Spring	
236	Barrel Adapter	
237	Gas Cylinder Tube Block	
238	Gas Cylinder Tube Block Washer (2)	
239	Gas Cylinder Tube Washer (2)	

- 240 Gas Cylinder Tube Link, Short - Right

PART			
NO.	NAME	OF	PART

- 241 Gas Cylinder Tube Link, Short - Left
- 242
- Gas Cylinder Tube Link, Long (2) Gas Cylinder Tube Link Joint Rivet (2) Gas Cylinder Tube Bar 2421/2
- 243
- 244 Barrel Changing Handle Clamp, Upper
- Barrel Changing Handle Clamp, Copper Barrel Changing Handle Tube 245
- 246
- Barrel Changing Handle Screw (2) 247
- 248 Barrel Changing Handle Nut (2)

These parts pertain only to the R 75 Rifle and are not used in R 75 A Rifle. Parts Nos. 52, 56, 60, 104, 225.

Factory Assemblies

PART NO.

382

PART NO.

- 380 Receiver comprises Parts 1, 2, 3, 4, 5(6), 221, 234, 235, 236
- 381 Gas Cylinder Tube comprises Parts 227B, 237, 238(2), 239(2), 240, 241, 242(2), 2421/2(2), 243

Barrel comprises Parts 56B, 57, 59, 60K, 61, 62C,

63, 64, 244, 245, 246, 247(2), 248(2)